




INSTALLATION GUIDE

48-AMA

COMPATIBLE PRODUCTS

PRODUCT	SKU
ROUND SINGLE OUTLET	48-O-FPE-B
ROUND SINGLE OUTLET	48-O-FPE-W
ROUND SINGLE OUTLET ROUND EARTH PIN	48-O-RPE-B
ROUND SINGLE OUTLET ROUND EARTH PIN	48-O-RPE-W
ROUND 1 GANG SWITCH GRID CLIPSAL SHAPE	48-1FC-B
ROUND 1 GANG SWITCH GRID CLIPSAL SHAPE	48-1FC-W
ROUND 1 GANG SWITCH GRID HPM SHAPE	48-1FH-B
ROUND 1 GANG SWITCH GRID HPM SHAPE	48-1FH-W

TOOLS



PH1 DRIVER | 2MM FH DRIVER | 48MM HOLE SAW | ALLEN KEY [INCL.]

INSTALLATION

Get on-site help - Scan the QR code for detailed installation instructions on this product and more.
zetr.com.au/installation

ⓘ ATTENTION

The safety of the device is guaranteed when the instructions and use are in-line with those outlined. It is recommended that this manual is stored safely and referred to throughout the life of the device.

⚠ DANGER


ELECTRIC SHOCK, EXPLOSION OR ARC FLASH HAZARD
Hazardous voltage and electrical current may be present at the wire leads of this product even when the device is switched off.

⚠ WARNING

When carrying out installation or maintenance, it is essential to isolate supply and follow the correct lock out and tag procedure at the point of supply before accessing the device.


- The device must be installed according to the instructions outlined in this document.
- The device must be installed with care, by a licensed electrician/ tradesman
- Installation must comply with Australian and New Zealand standards ASNZ3000.
- Pay attention to the wiring diagrams and specifications related to the installation.
- Do not use this product for any other purpose than specified in this manual.
- If any part of the device is damaged prior to installation it must be replaced/repaired by the manufacturer or licensed service agent prior to installation
- The device must not be modified, or force fit. Any modification or non-compliant installation will jeopardise system safety and/or result in equipment damage or malfunction.
- ZETR forfeits any liability and warranty for any modified product and/or installation

1




Using a 48mm diameter hole saw, cut a clean hole ensuring that the exposed edges of the substrate are clean.
ⓘ **ATTENTION** The edge will be left exposed.

2




Using the allen key provided, loosen the 3x dovetail washers contained in the mounting assembly.

3




The inner shroud should freely move back and forth within the mesh frame.

4




Pull the cable through the mounting assembly and thread through the hole cut-out.

5




Using self-tapping screws or adhesive, fasten the mesh to the back side of your substrate, then push the inner shroud through the cut-out.
N.B. Consult your substrate fabricator or contractor for best fastening method.

6




Tuck the cable into the inner shroud.

7




Adjust the inner shroud so it is flush to the front-side of your substrate.

8




Using the allen key provided, tighten the 3x dovetail washers to set the inner shroud.

9




Remove the faceplate from the outlet/switch grid.

10




A. Remove the screw from the circlip using a philips head screwdriver.
B. Remove the circlip using a flathead screwdriver, lever this out by using the notch.
N.B. Safely store all components until required.

11




Terminate wiring or desired service.
N.B. If installing a switch grid, insert your mechanisms prior to termination.

12




Using long nose pliers, insert the device into the mounting accessory, ensuring that the arrows on the shroud and the device are aligned.

13




Turn the device clockwise until the arrow is pointing directly up and the device stops rotating.

14



Push the circlip into the provided slot and fasten with M2.5×8mm screw, previously removed.

15



Snap fit the faceplate to the device.
Wipe the device with a soft damp cloth or detergent-impregnated wipes to complete installation.

END




INSTALLATION GUIDE

48-FMA

COMPATIBLE PRODUCTS

PRODUCT	SKU
ROUND SINGLE OUTLET	48-O-FPE-B
ROUND SINGLE OUTLET	48-O-FPE-W
ROUND SINGLE OUTLET ROUND EARTH PIN	48-O-RPE-B
ROUND SINGLE OUTLET ROUND EARTH PIN	48-O-RPE-W
ROUND 1 GANG SWITCH GRID CLIPSAL SHAPE	48-1FC-B
ROUND 1 GANG SWITCH GRID CLIPSAL SHAPE	48-1FC-W
ROUND 1 GANG SWITCH GRID HPM SHAPE	48-1FH-B
ROUND 1 GANG SWITCH GRID HPM SHAPE	48-1FH-W

TOOLS



PH1 DRIVER | 2MM FH DRIVER | 48MM HOLE SAW | ALLEN KEY [INCL.]

INSTALLATION

Get on-site help - Scan the QR code for detailed installation instructions on this product and more.
zetr.com.au/installation

ⓘ ATTENTION

The safety of the device is guaranteed when the instructions and use are in-line with those outlined. It is recommended that this manual is stored safely and referred to throughout the life of the device.

⚠ DANGER


ELECTRIC SHOCK, EXPLOSION OR ARC FLASH HAZARD
Hazardous voltage and electrical current may be present at the wire leads of this product even when the device is switched off.

⚠ WARNING

When carrying out installation or maintenance, it is essential to isolate supply and follow the correct lock out and tag procedure at the point of supply before accessing the device.


- The device must be installed according to the instructions outlined in this document.
- The device must be installed with care, by a licensed electrician/ tradesman
- Installation must comply with Australian and New Zealand standards ASNZ3000.
- Pay attention to the wiring diagrams and specifications related to the installation.
- Do not use this product for any other purpose than specified in this manual.
- If any part of the device is damaged prior to installation it must be replaced/repaired by the manufacturer or licensed service agent prior to installation
- The device must not be modified, or force fit. Any modification or non-compliant installation will jeopardise system safety and/or result in equipment damage or malfunction.
- ZETR forfeits any liability and warranty for any modified product and/or installation

1




Mark out the centre for the location where you intend to install your outlet/switch grid.

2




Using a 48mm hole saw, cut a single hole, using your marking as the centre point.

3




A. Insert the mesh panel into the hole. Once inserted, hold flat against the back of the wall.
B. Drive self-tapping screws from the front of the wall through the plasterboard and mesh to fasten.

4




Pull the cable through the hole cut-out and thread through the mounting accessory.

5




Insert 48-FMA into the hole cut-out, drive self-tapping screws through the mounting accessory, plasterboard and mesh to fasten.

6




Tuck the cable into the body of the mounting accessory.

7




Apply wall medium using spatula or trowel ensuring that the edges are tapered.

8




A. Sand the plaster, ensuring that the edges are feathered and the transition between wall and mounting assembly is smooth.
B. Paint over the top. For best results and uniformity, we recommend the entire wall/ panel is painted.

9




Remove the faceplate from the outlet/switch grid.

10




A. Remove the screw from the circlip using a philips head screwdriver.
B. Remove the circlip using a flathead screwdriver, lever this out by using the notch.
N.B. Safely store all components until required.

11




Terminate wiring or desired service.
N.B. If installing a switch grid, insert your mechanisms prior to termination.

12




Using long nose pliers, insert the device into the mounting accessory, ensuring that the arrows on the shroud and the device are aligned.

13




Turn the device clockwise until the arrow is pointing directly up and the device stops rotating.

14



Push the circlip into the provided slot and fasten with M2.5×8mm screw.

15



Snap fit the faceplate to the device.
Wipe the device with a soft damp cloth or detergent-impregnated wipes to complete installation.

END